

## G300 Freezefog Activation

For G300's that have the Freezefog output modification.

The Freezefog will be activated when the smoke switch is in the On position, regardless of the smoke output level.

Smoke will be emitted when the output is turned up. This allows manual control of the time delay between Freezefog activation and smoke issue.

There is an internal adjustment preset which will allow a time delay of smoke issue after it has been activated. This is accessible after removing the control panel section.

This is set by the 'upper' preset. When turned fully clockwise a delay of 6 seconds will occur before smoke issue. (for easy set usable delay). A fuller range of time delay (>6sec) is available as the preset is varied between its mid-position and nearly fully clockwise.

This presettable function allows simple action of the overall effect by having the smoke output set, and just switching the smoke to 'On'.

To reduce the delay to zero, turn the upper preset fully anticlockwise.

In the DMX mode, Channel 1 controls the smoke output level, whilst Channel 2 controls the Freezefog.

Again, if any delay is set via the internal preset, this will take effect when activated, allowing simple control.

Single channel operation is possible by setting the DMX remote smoke output to manual, and just using the 'smoke switch' channel.